

## Montageanleitung Kettenspanner Mounting instructions Chain Adjuster

Stand 01/02/11

### Einbauhinweis:

1. Bauen Sie die Steckachse des Hinterrades aus.
2. Entfernen Sie die original Kettenspanner und setzen die neuen ein.
3. Die Einbaurichtung richtet sich nach den von Ihnen verwendeten Kettenrädern. Wenn Sie ein größeres Kettenrad verbaut haben, sollte der „alpha Racing“ Schriftzug in Richtung Vorderrad zeigen.
4. Durch das drehen des Kettenspanners können Sie eine Zahnabweichung von Minus 1 Zahn ausgleichen.
5. Bauen Sie die Steckachse wieder ein.
6. Überprüfen Sie die Kettenspannung. Beachten Sie hierzu bitte die Vorgaben bzw. Hinweise Ihrer Bedienungsanleitung.

### Mounting instructions:

1. Remove from the axel of the rear wheel
2. Remove the original chain tensionier and put the new one
3. The installation direction depends on the use of your sprockets. If you have used a larger sprocket, should the "alpha Racing" logo facing towards the front wheel.
4. By the turn of the chain tensionier, you can correct a tooth difference of minus 1 tooth.
5. Remove the axle again.
6. Check the chain tension. Please refer to the guidelines and instructions of your manual.

